All Weather Greens

INSTALLATION GUIDE · MESH METHOD

Quick Install Guide

Artificial green wall panels — from bare wall to finished green wall in 8 steps.



WHAT YOU'LL NEED

Tools

- Tape measure & pencil
- Spirit level
- Drill + masonry bit
- Screwdriver
- Scissors & utility knife
- Step ladder
- Safety glasses & mask

Materials

- Green wall panels
- Plastic grid mesh
- Wall plugs & screws
- Large washers
- Cable ties

PLAN YOUR PANELS

50 × 50 cm panel	**4 per m²**
100 × 100 cm panel	**1 per m²**

Example: 3 m × 2.4 m = 7.2 m²
→ 29 panels + 10% spare =
32 panels (50 × 50 cm)

PART 1 Mount the mesh



Measure the wall

Measure width × height for m². Mark the outline with a pencil and level.



Cut the mesh

Cut the plastic grid mesh to size. On wide walls, join sheets edge to edge.



Drill fixing holes

Mark fixing points about every 40–50 cm, then drill and insert wall plugs.



Fix the mesh

Screw the mesh to the wall through large washers — flat, tight and level.

PART 2 Hang the panels



Unbox the panels

Cut cartons open shallowly so you don't nick the leaves. Check the count.



Lay out & fluff

Fluff the leaves after shipping. Mix and rotate panels so seams disappear.



Hang the panels

Start at a top corner and work across row by row, panels pressed tight.



Secure with ties

Tie each panel to the mesh at corners and centre. Pull tight, trim the tails.

SAFETY

Check for hidden pipes and cables. Wear glasses and a mask.

OUTDOORS

Use stainless or galvanised screws and UV-resistant ties.

FINISHING

Trim panels with scissors to fit edges, then fluff once more.

CARE

Dust or rinse lightly. Keep away from open flames.

© 2026 All Weather Greens
allweathergreens.com sales@allweathergreens.com WhatsApp +86 135 3752 5123